




## CONTROL PANEL PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)

27" BUILT-IN ELECTRIC  
DOUBLE OVEN  
SELF CLEAN UPPER  
AND  
STANDARD CLEAN LOWER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)

**Illus. Part**  
**No. No. DESCRIPTION**

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		End Cap, Left
	3188123	Black Model
	3188125	White Model
		End Cap, Right
	3188124	Black Model
	3188126	White Model
2		Trim, Top
	3187971	Black Model
	3187969	White Model
	3185648	Screw
3		Trim, Center
	3183573	Black Model
	3187962	White Model
4		Door, Vent
	3183501	Black Model
	3187981	White Model
5		End Trim
		(Vent Door)
		Left Hand
	3148697	Black Model
	3148471	White Model
		Right Hand
	3148698	Black Model
	3148472	White Model

**Illus. Part**  
**No. No. DESCRIPTION**

6		Trim, Bottom
	3184408	Black Model
	3188153	White Model
	342043	Screw
7		Control Panel
	3184650	Black Model
	3184651	White Model
8		Stiffener, Bracket
	3183492	
	3149333	Screw
9		Trim, Vent
		Upper
	3184589	Black Model
	3184588	White Model
	3185647	Screw (4)
11		Electronic Timer
	3169256	Black Model
	3169257	White Model
12		Insert, Vent
	3185647	Screw
13		Bracket, Vent
		Insert
	3185648	Screw
14		Switch, Rocker
	3182717	Black Model
	3182718	White Model
15		Stiffener, Bracket
	3149333	Screw

**Illus. Part**  
**No. No. DESCRIPTION**

16		Knob, Thermostat
	3183106	Black Model
	3183107	White Model
17		Knob, Selector
	3183109	Black Model
	3183110	White Model
18		Switch, Selector
	155023	Screw (2)
19		Thermostat
	3169303	
	3178002	Screw (2)
20		Light, Indicator
21		Lens, Light
	309133	Screw (4)
22		Clip

## **FOLLOWING PARTS NOT ILLUSTRATED**


## **LITERATURE PARTS**

LIT3186642	Tech Sheet
LIT3183636	Installation
	Instructions
LIT3188184	Use & Care Guide

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS

For Model: RB770PXBBO, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS


For Model: RB770PXBBO, RB770PXBQO  
(BLACK)(DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			16	3179848	Clip, Oven Seal	35	3179922	Tube, Vent (Upper, Female)
2	3177545	Bracket, Conduit	17	3177681	Bracket, Switch		3185647	Screw
3	3177623	Cabinet, Back	18	3177923	Insulator, Switch	36	3184652	Vent, Tube (Upper, Male)
	3185647	Screw	19	3177621	Bottom, Module		3185647	Screw
6	3178143	Cabinet, Top	20	3179220	Rail, Support (2)	39	4168203	Cover, Cap Tube
	3185647	Screw		3185647	Screw		4159445	Screw
7	3183748	Top, Module	22	3177434	Support, Oven	41	3183752	Bracket, Control
8	3177440	Side, Cabinet	23	3178612	Shield, Radiation		3177991	Screw (2)
9	3181699	Tube, Vent		3185647	Screw	42		Side, Trim
	3185648	Screw (3)	24	3177433	Bracket, Hinge			Door (2)
10	3150505	Oven Light Assy.		3179795	Screw (6)		3187875	Black Model
11	3184533	Gasket, Light	26	3177560	Back, Module		3187878	White Model
12	311255	Bulb, Oven Light	27	3185562	Liner, Oven	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
13	313382	Clip, Thermostat Bulb	28	3178298	Hinge, Door (2)			
14	3185861	Frame, Front		3179795	Screw (4)	<b>INSULATION</b>		
15	3179813	Seal, Door	30	3182814	Button, Plug			
			31	4173553	Switch, Door		3185551	Insulation, Wrap
				4159117	Nut (2)		3177872	Insulation, Back
				313489	Screw (2)			
			33	3179587	Retainer, Seal			
				4168863	Screw			
			34		Vent, Middle Trim			
				3187889	Black			
				3187891	White Model			
				3180022	Screw (4)			
				4173601	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN PARTS

For Model: RB770PXBBO, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN PARTS


For Model: RB770PXBBO, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			18	3177433	Bracket, Hinge (2)	30	4173553	Switch, Door
				3179795	Screw (6)		4159117	Nut (2)
			19	3177621	Bottom, Module		313489	Screw (2)
			20	3178612	Shield, Radiation	31	3149653	Thermostat
				3185647	Screw		3185647	Screw
3	3183748	Top, Module	21	3177434	Support, Oven	32	3179587	Retainer, Seal
4	3181700	Tube, Vent	22	3177560	Back, Module		4168863	Screw (2)
	3185648	Screw (3)		3185648	Screw	33	4168203	Cover, Cap Tube
5	3185562	Liner, Oven	23	3180126	Cover, Latch Mtg.		4159445	Screw
7	311255	Bulb, Oven Light		3185647	Screw (2)	34		Trim, Lower Vent
8	3184533	Gasket, Light	24	3179848	Clip, Seal (3)		3177783	Black model
9	3150505	Oven Light Assy.	25	3178298	Hinge, Door (2)		3177789	White Model
10	313382	Clip, Bulb (2)		3179795	Screw (4)	35	3184208	Plate, Cover
12	3177688	Frame, Front	26	3185085	Button, Plug		3185648	Screw
13	3179813	Seal, Door	27	3182814	Button, Plug	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
14	3177681	Bracket, Switch	28	3179945	Tube, Vent (Male)			
	3177991	Screw (2)		3185647	Screw	<b>INSULATION</b>		
15	3177923	Insulator, Switch	29		Tube, Vent (Female)			
16	3177551	Bottom, Oven		3187388	Black Model		3185551	Insulation, Wrap
17	3179220	Rail, Support (2)		3181964	White Model		3177872	Insulation, Back
				3185647	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN DOOR PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			5	3185437	Insulation	13		Handle, Door
1	3185497	Liner, Door		4168863	Screw		3187946	Black Model
2	3178001	Screw (2)	7	3185458	Glass, Reflective		3187944	White Model
3	3185462	Gasket, Window	8	3185438	Plate, Latch		355515	Screw
4	3185457	Glass, Clear		3185647	Screw	14		Spacer
5	3185460	Insulation, Door	9	3185439	Retainer, Glass		814282	Black Model
			10	3185459	Glass, Clear		814281	White Model
				3185647	Screw	16	3188633	Foil-Adhesive
			11		Frame, Door	17	3188599	Bushing
				3187850	Black Model		3184042	Screw
				3187852	White Model	18	3188635	Foil-Adhesive
			12		Glass, Door			
				3187868	Black Model			
				3187870	White Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN DOOR PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			7	3187868	Glass, Door Black Model	11	814282	Spacer Black Model
1	3185498	Liner, Door		3187870	White Model		814281	White Model
	3178001	Screw (2)	9	3187850	Frame, Door Black Model	13	3185457	Glass, Clear
2	3185462	Gasket, Window		3187852	White Model	16	3188599	Bushing
5	3185437	Insulation, Retainer	10	3187946	Handle, Door Black Model		3184042	Screw
	4168863	Screw		3187944	White Model			
				355515	Screw (2)			
				4168863	Screw			
				4173601	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# COMPONENT SHELF AND LATCH PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3184592	Shelf, Component
	3185647	Screw
2	258076	Block, Terminal
	308043	Screw
	3185647	Screw
3	4159035	Bushing
4	3178671	Switch, Latch
5	3178185	Insulator, Switch
6	3177662	Guard, Latch
	3177991	Screw
	254225	Screw
7	3177969	Handle, Latch
8	3184039	Knob, Latch
		Handle
	3183294	Screw
9	3184041	Spacer, Latch
		Handle
	3184042	Screw (2)
10	3178410	Latch Mechanism
11	3177496	Plate, Mounting
	3185647	Screw
	3179116	Screw
12	3179777	Button, Plug
13	3178132	Extension, Shelf
	3177991	Screw
	3185647	Screw
		Bottom (2)
15	3178187	Switch, Latch
	3177988	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3185562	Liner, Oven
2	660579	Element, Broil
	3182950	Retainer (2)
	3185648	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3185367	Rack, Offset
6	3185368	Rack, Oven (2)
7	661416	Element, Bake
	3185648	Screw (4)
9	3148440	Sensor, Heat
	3185648	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

For Model: RB770PXB0, RB770PXBQ0  
(BLACK)(DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
1	3187607	Harness Wire (Door Switch Upper)
2	3183656	Harness, Wire (Door Switch Lower)
3	3186591	Harness Wire (Lower Oven)
4	3186590	Harness Wire (Upper Oven)
5		Clamp
	3184791	3/8 I.D.
	3184792	3/4 I.D.
	3148107	Screw
	3185647	Screw
6	3179668	Standoff, Wire
	3185647	Screw
8	309551	Connector, Line Splice
9	3186593	Wiring Harness (Latch Assembly)
	112432	Nut, Hex (3)
10	3186594	Wiring, Harness (Latch Assembly Lower)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST